





## **TO OPEN**

Rotate the slats by turning the wand until the slats are in the open position prior to sliding the blinds open with the wand.

## **CLEANING**

All of our products are designed to require minimal care and maintenance, but we do recommend that you dust regularly with a soft cloth or feather duster. This will maintain a like-new appearance. For some of the vinyl fabrics or vertical vanes, you can wipe off any dirt or stains with a damp cloth when necessary. You may also use compressed air from a can or the brush attachment from your household vacuum to dust off selected products. We do not recommend the use of any detergents as this may damage the product.

Do not try to slide the verticals open (305) 623-4855 · info@abetterblind.com · www.abetterblind.com while the slats are in the closed position.

© 2019. A Better Blind. All Rights Reserved

